

---

## f a s t e n e r   s c h e d u l e

When nailing or stapling BR-111™ Exotic Hardwood Flooring a minimum of two fasteners per plank, spaced 1" - 2" from each end must be used to secure the hardwood floor to the approved sub-floor.

- - 3/4" X 3" solid fasten every 8" - 10"
  - 3/4" X 5 1/2" and wider fasten every 4" - 6"
  - Use 2" cleats or staples
- - 7/16" X 2 5/8" solid fasten every 3" - 4"
  - Use 1 1/4" cleats or 1 1/4" 18 gauge staples
- - 5/16" X 3 1/8" solid fasten every 3" - 4"
  - Use 1" cleats or 1" - 18 gauge staples\*
- \* 18 gauge staples are recommended due to the hardness of some exotic hardwood species.
- - 3/8" Engineered fasten every 3" - 4"
  - Use 1 1/4" staples

**DO NOT NAIL OR STAPLE 5/16" ENGINEERED FLOORING**